## TECHNICAL DATA SHEET

# UMITAN EZ / PS POLV.

Bating CLASSIC FOR PRECIOUS SKINS

CHEMICAL COMPOSITION

Mixture of pancreatic enzymes

#### **FEATURES**

Appearance: clear powder granulosa

pH in solution at 10%: 7-8

Enzyme units: I.V. About 500

Field of activity: pH 7-8

# **PROPERTIES**

UMITAN EZ / PS pow. is a classic bating for fine leathers type calves and kids, which cleans the flower making fine and elastic. UMITAN EZ / PS when used at low percentages is used for the processing of hides which must keep a feel supported, but if used at higher dosage is used for soft leather type tassel and softy. The action of UMITAN EZ / PS is still strong, and should be followed carefully processing times, which should never be too long.

### HOW TO USE

We list below the doses recommended for some of the most common types of leathers:

- Calves for upper is used from 0.4% to 0.8%
- Bovine hides for uppers using from 0.4% to 0.8%
- ♦ Bovine hides for nappa is used by 1% to 1.5%
- Kids using 1.5% to 2%
- Montoni for upper or lining is used from 0.6% to 0.8%
- Pigs clothing using 1.5% to 2.5%