

TECHNICAL DATA SHEET UMITAN O / R32 LIQ. REDUCING THE FREE FORMALDEHYDE

FEATURES

Appearance: colorless liquid perfumed

Active substance: 25 - 30% pH in solution at 10%: 5 - 6

PROPERTY

UMITAN O / R32 liq. It has been developed to meet the regulations in the field of free formaldehyde contained in the skins. UMITAN O / R32 complex the free formaldehyde in the skin, transforming it into a soluble product, the move from the skin in the bath, removing it with a simple washing. UMITAN O / R32 does not affect the final article i, or on skin color. With the use of UMITAN O / R32 you can then get those results that the regulations require.

UMITAN O / R32 can be used on all types of leather.

HOW TO USE

Using the UMITAN O / R32 1 to 2% during the final wash, with rotation of thirty minutes.

DATA AND NEWS HAVE VALUES



INTISO chemicals

di Intiso Pietro Livio