

TECHNICAL DATA SHEET

UMITAN RI/GA POLV.

AUXILIARY FILLING

CHEMICAL COMPOSITION

Mixture of protein substances minerals

FEATURES

Appearance: fluid paste sleek beige
Active substance: approximately 40-45%

pH in solution at 10%: 6.5 - 7.5 Ionic charge: nonionic

Compatibility: anionic and non anionic

PROPERTY

UMITAN RI / GA pow. is used on all types of chrome tanned leather, where you require excellent qualities of filling and fullness. UMITAN RI / GA acts on the skin in a highly selective, filling the empty areas and ensuring a thickening of the flower and uniformity throughout the treated skin. UMITAN RI / GA can be used on corrected grain leather, suede on crusts intended to improve the qualities of buffing. Since UMITAN RI / GA a product nonionic and having a good fastness to light, is used not only for the production of white skins but also for those pastel colors without changing the color tone.

HOW TO USE

In retanning phase is used from 2% to 4% for the upper and from 2% to '8% for the crusts.

In fattening phase is used by 1% to 3% in admixture with oils. The above percentages refer to the shaved weight.

DATA AND NEWS HAVE VALUES